


CZXT199.516



20				
19	GB93-87	Spring Washer 10	32	Zn Plated
18	GB93-87	Spring Washer 8	4	Zn Plated
17	GB97.1-85	Washer 10	4	Zn Plated
16	GB97.1-85	Washer 10	32	Zn Plated
15	GB97.1-85	Washer 8	100	SS
14	GB6170-86	Nut M10	32	Zn Plated
13	GB6170-86	Nut M8	4	Zn Plated
12	GB5783-86	Bolt M10X30	32	Zn Plated
11	GB5783-86	Bolt M8X16	4	Zn Plated
10	GB5783-86	Bolt M8X25	96	SS
9	CZXT912.003	Cell Numerals	1Set	
8	CZXT831.002	Inner Shield Plate	2	
7	CZXT833.005-2	Base	2	
6	CZXT651.120	Inter-tier Connector	42	Solid
5	CZXT651.147	Main Terminal Connector	2	Solid
4	CZXT651.140	Inter-row Connector	2	Solid
3	CZXT872.014	Outer Shield Plate	2	
2	CZXT658.000	Insulating Bracket	2	
1	CZXT321.056	GTS6-800L MODULE	8	
No.	Code	Parts Description	Qty.	Remarks

NOTES:

- 1) Refer to installation and operating instruction (fig.8) for Intermodule Assembly.
- 2) Refer to installation and operating instruction (fig.5) for the Assembly of the lower module and base.

					48V		CZXT199.516	
					GTS6-800L MODEL			
					GENERAL ASSEMBLY			
							Sheet No: 1 of 1	
							GASTON BATTERY	
Mark	Qty.	Change	Signature	Date				
Designed by								
Checked by								
Approved by								

CAD No.

Previous
Previous No.

Previous No.

Signature

Date